

Bugflector

Quick and Easy Installation Instructions

CONTENTS

- (1) hood protector
- (2) fender protectors
- (2) alcohol wipe pads
- (2) bump-ons
- (4) screw fasteners
- (1) instruction sheet

IMPORTANT: Read all instructions carefully before beginning installation. Installation utilizes the existing holes in the grill which align with the holes in the Bugflector. The ideal installation temperature is between 65°-110°F (18°-43°C).

STEP 1

Locate the (4) circular holes on the underside of the front grill. Clean the area around the holes with a clean cloth to remove any dust or debris which may affect the mounting of the Bugflector. See FIGURE 1

STEP 2

Align the predrilled holes in the Bugflector with the holes in the underside of front grill.

STEP 3

Using a Phillips screwdriver, install the fastener. **TO PREVENT STRIPPING FASTENER, SCREW UNTIL SNUG; DO NOT OVERTIGHTEN.** Repeat procedure for the remaining holes. See FIGURE 2

FENDER PROTECTOR INSTALLATION

STEP 4: Clean the fender protector tape mounting location on the fender with an alcohol pad and wipe dry with a soft cloth. See FIGURE 3. To reduce the risk of tape contamination due to improper positioning, expose only 2" (5 cm) of tape from each end of the tape flange by peeling back liner. There may be more than one tape flange. Be sure that the free ends of the liner can be easily accessed later. See Diagram A

STEP 5: Align the fender protector with the front edge of the fender. Press firmly to adhere the previously exposed tape to the fender and verify position. With the fender protector in its final position, remove the remainder of the tape liner by pulling on the free ends. Press firmly along tape flanges to ensure tape has adhered properly to the fender. Adhere a bump-on at the indicated position. See Figure 4

Repeat steps 4 through 5 for opposite side fender protector.

